

# Posture Phase 7

# Never Flip



- Panel Quilt:**
  - 3/4" Densified Quilting Fiber
  - Jones 610 Cotton Fire Barrier
  - 2" Foam
- Topper/Insulator:**
  - 3/4" Quilted Cotton Backing
  - 2" Foam
  - Perf Pad
- Spring Unit:**
  - 416 14 1/2 Guage Spring Unit
- Base:**
  - Perf Pad
  - 2" Foam
  - Soster Nonskid Surface